

Wasswa Charles Sewagudde

Design of a Wireless Gesture Activated PowerPoint Controller

Helsinki Metropolia University of Applied Sciences Bachelor of Engineering Information Technology Bachelor's Thesis 8 April 2011



Author	Wasswa Charles Sewagudde	
Title	Design of a Wireless Gesture Activated PowerPoint Controller	
Number of pages	69 pages + 3 appendices	
Date	8 April 2011	
Degree	Bachelor of Engineering	
Degree Programme	Information Technology	
Specialization Option	Embedded Systems Engineering	
Supervisor	Anssi Ikonen, Senior Lecturer	

The desire to give effective presentations lead to the development of different types of visual aids including flip charts, overhead transparencies, posters and digital slide shows. The digital slide shows had improved the effectiveness of the presentation and the audience size, but the need to be next to the keyboard or mouse, created a vacuum for new innovations. There was a need for some form of wireless control of the slides movement. Presenters have always wanted the freedom of movement during their presentation sessions.

The purpose of this project was to design and implement a device that would provide the remote control of PowerPoint slide shows. The project was started by gathering the specification requirements from which design requirements were derived. The selection of the required components was done after thorough examination of dependencies between the different parts of the project. The implementation phase started with the hardware followed by the software. The final phase was testing through which all modules from both the software and hardware were tested before the integration testing was carried out.

The objective of the project was achieved and now it is possible to control the slides remotely using a gesture. The Wireless Gesture activated PowerPoint Controller (WGPC) will give presenters the freedom of movement during their presentations. By imitating book-page opening and closing, with the controller tied on the arm, a presenter is able to move the slides back and forth.

Keywords	IIC, I2C, SPI, USB, ISM, gyroscope, accelerometer,
	Bluetooth, infrared

## Acknowledgements

There are some challenges in life we tend to shy away from, not because we cannot confront them, but because we do not know that we have the strength and what it takes to face them. It is after a good neighbor telling us how talented we are, that we realize that we are better than what we thought we really are. After toppling a number of problems, we acquire experience, skills, competence and a feel that we may not be as weak as we think, after all. I have gone through an experience similar to this, during this project; therefore I must thank those good neighbors who lent a hand before, during and after the project.

I would like to extend my sincere gratitude to all the persons who contributed, in one way or the other, towards the successful completion of this project, especially the staff and students of Metropolia UAS. I cannot mention all of you here due to your big number but allow me point out a few. First and foremost, I would like to thank my supervisor Mr. Ikonen Anssi for his inspiration, encouragement and support during the project. Thank you for trusting me with your project idea. I will always remember these words you said to me when you detected some hesitation in my eyes. "You're one of the bright students I have taught, you can do this project, am sure. I have the confidence in you, you always produce good results".

Secondly, I wish to thank Dr. Piironen Antti for listening to me whenever I had troubles with the project, particularly the sensor. Thank you for teaching me to be a good engineer. Thirdly, I wish to extend my thanks to the language adviser, Ms. Taru Sotavalta for helping me correct this document to meet the standards of an academic paper. Last but not the least I would like to thank my fellow students especially Mr. Joseph Hotchkiss and Mr. Lawrence Nwaogo for their constructive arguments which helped me find solutions at the times when my ideas ran dry.

Lastly, I would like to thank my family for their endurance and moral support. I especially wish to thank my sister, Ms. Juliet Namazzi for her encouragement and advice. I felt honored when you said to me, "It is no longer about you, it is about us. You're our flag bearer. Your failure is our failure."

"The *mind*, once expanded to the *dimensions* of *larger ideas*, *never* returns to its original size" (Oliver Wendell Holmes)

Contents Abstract	2
Acknowledgements	
1 Introduction	8
2 Overview of Interfacing Technologies	9
2.1 Interfacing in Brief	
2.2 RS232 (EIA232)	9
2.3 Universal Serial Bus (USB)	11
2.3.1 Common USB Terminology	11
2.3.2 The Evolution of USB Standards	
2.3.3 USB Technologies	12
2.3.4 USB Connectors	
2.3.5 USB Communication	13
2.3.6 USB Device Classes	17
2.3. 7 Advantages of USB Interfaces	18
2.4 Inter-Integrated Circuit (IIC) Bus	18
2.4.1 Features of IIC Bus	19
2.4.2 The IIC Bus Protocol	20
2.4.3 IIC Bus Used as an Interface	20
2.4.4 IIC Bus Data Format	21
2.5 Serial Peripheral Interface (SPI)	21
2.5.1 Data Transmission	22
2.5.2 Advantages of SPI	23
2.5.3 Disadvantages of SPI	24
3 Wireless Technologies	24
3.1 Overview	24
3.2 Radio Frequency Spectrum	25
3.3 Industrial, Scientific and Medical Band (ISM)	26
3.4 Bluetooth	27
3.4.1 Interfacing PC with Bluetooth	27
3.4.2 Versions of Bluetooth Specifications	
3.5 Infrared	29

Re	eferences62
	Conclusion61
	7.5 Future Developments59
	7.4 Integration Testing59
	7.3 Transmitter and Receiver Software Testing
	7.2 Transmitter and Receiver Hardware Testing 56
	7.1 Testing Overview56
7	Testing
	6.3 Receiver Software Design53
	6.2 Transmitter Software Design51
	6.1 Overview51
6	Software Design51
	5.6 Design Challenges 50
	5.5 Tools and Equipment50
	5.4.3 Final Receiver Design48
	5.4.2 Microcontroller Selection
	5.4.1 Computer Interface Selection
	5.4 Receiver Design
	5.3.4 Final Transmitter Design
	5.3.3 Microcontroller Selection
	5.3.2 Radio Frequency Transceiver Chip Selection
	5.3.1 Sensor Selection
	5.3 Transmitter Design 38
	5.2 Requirements and Specifications
_	5.1 Overview
5	Hardware Design
	4.4 Gyroscopes
	4.3 Acceleration sensors
	4.2 Sensor Terminology
	4.1 An Overview
4	Sensor Technology30

4	ppendixes	65
	Appendix 1: WGPC Sensor Module Schematics and PCB	65
	Appendix 2: Transmitter C-Program codes	66
	Appendix 3: Receiver C-Program Codes	B

### 1 Introduction

The desire to give effective presentations has been the driving force for the invention of visual aids. There are several types of visual aids that have been developed to the effect, such as: flip charts, overhead transparencies, posters or digital slide shows. The challenge remained on the ease of use during the presentation session. The digital slide shows had improved the effectiveness of the presentation and the audience size, but the need to be next to the keyboard or mouse, created a vacuum for new innovations. There was a need for some form of wireless control of the slides movement. [1]

The purpose of the project was to design a controller that would change the slides remotely, without contact to the computer keyboard or mouse. The controller would allow the presenter to change the slides without being a captive to the keyboard or mouse. The presenter would have improved contact to his or her audience due to increased freedom of movement.

The main objective of this paper is to highlight the steps that were used during the design process and the technologies that were relevant to the project. The scope of the project was limited to controlling PowerPoint slides remotely, so is this report.

# 2 Overview of Interfacing Technologies

# 2.1 Interfacing in Brief

Interfacing refers to connecting two or more devices together so that they are able to exchange information. Scientists and engineers have done a commendable job in finding the best ways in which devices can communicate with one another, and the choice of which method to use is dictated by the nature of the application involved. This project aims to find the best and easiest way to interface a computer with other devices or peripherals. Some of the popular PC interfacing technologies available are discussed here. The wired technologies are discussed in sections 2.2, 2.3, 2.4 and 2.5. The wireless technologies are covered in sections 3.4 and 3.5.

## 2.2 RS232 (EIA232)

Computers have serial ports which are also known as the RS232 port. Data from the peripherals is transferred in serial form to the computer or terminal. The drawback for this interface is the need to convert the serial data back to parallel format before being used [2]. Actually, data is naturally parallel; it is converted to serial for transmission and converted back to parallel for "consumption". The implementation of serial communication is achieved by the use of Universal Asynchronous Receiver Transmitter (UART). Devices interfaced via the serial cable are either Data Communication Equipment (DCE) such as modems, and plotters or they are Data Terminal Equipment (DTE) which is normally the computer or terminal. [2]

The RS232 is an old standard that defines the voltage levels and other parameters used in serial communication. RS232 serial ports have two types of connectors: D9 and D25. The D9 is a 9- pin connector whereas D25 is 25 pins [2]. The UART is crucial in the situation where data is exchanged between devices and the computer and is the main component of R232. It takes care of the serial-to-parallel conversion of data from the device to the computer and parallel-to-serial conversion of the data from the PC to the device. A UART-

constructed data packet consists of four parts: start bit, data bits, parity and stop bit. [3] Figure 1 illustrates the UART data format.




Figure 1 : UART Data Format [3]

The start bit makes the beginning of the data to be transmitted, and it alerts the receiving device to get ready to receive incoming data in addition to causing the receiver clock to synchronize with the transmitter's clock. The parity bit is used for error checking and the stop bit indicates the end of the data word. The start bit, the parity bit and the stop bit are always automatically discarded by the receiver. The stop bit must always be sent. Otherwise if it is not detected at the end of a data word, the receiver rejects the whole data word and reports a framing error. [3]

Interfacing the computer via RS232 port has some advantages, they include advantages such as:

- longer cables connections between the device and the computer with minimum cable loss
- only two wires are needed, the transmit data (TXD) and receive data (RXD) [2].

Some of the disadvantages of using RS232 include:

- the drivers are needed for the PC to be able to understand the data being read
- RS232 lever shifter is always needed
- only one device can be connected to one port
- RS232 cannot be used as the power source for low power devices
- maximum data rate is 1 Mbps [3].

Most of the new computers produced today, especially laptops; have the serial port replaced by new technologies such as Bluetooth and USB.

## 2.3 Universal Serial Bus (USB)

A universal serial bus is a serial bus standard for connecting devices, usually peripheral devices, to computers. The USB standard is promoted by the USB Implementers Forum (USB-IF). It is one of the popular means of interfacing with computers due to its impressive performance and ease of implementation. This has led to many PCs and most handheld devices to abandon the parallel and serial ports. [4, 5]

## 2.3.1 Common USB Terminology

The common USB terminologies are illustrated in figure 2. Devices are input/output peripherals that communicate with a terminal/computer; they can be connected via a Hub or connected directly to a USB port onto the terminal. A Hub is a device with additional downstream USB ports whereas a Host is the master that controls the transactions and it is normally a computer though other devices can also be the Hosts. [6]




Figure 2: Standard USB Nomenclature [6]

There are two kinds of hubs; the bus powered that draws power directly from the host USB interface, and the self-powered that has an in-built power source [4]. The cables that interconnect the components in a USB network are commonly referred to as USB cables. There are some input/output devices that also have USB ports; an example is a keyboard. These types of devices are called Compound Devices, whereas those that implement two or more different functions are called Composite Devices. [6] Another example of a compound device is a webcam with an inbuilt microphone.

#### 2.3.2 The Evolution of USB Standards

There are three version for USB standards; the USB 1.1, USB 2.0 and USB 3.0. The USB 1.1 standard was the first to be developed; it uses a tiered star topology capable of supporting up 127 devices with a maximum of 6 hubs. It uses a slave/master (host) relationship with a PC; usually the PC is the master and all other connected devices are the slaves. The USB 1.1 standard defines two data transfer rates; the Low Speed which is 1.5 Mbps and Full Speed of 12 Mbps. The cable length is limited to a maximum of 5 meters and the devices should not draw more than 500 mA of power. [5]

The USB 2.0 has few modifications from the first version; the additional feature is the high speed mode with 480 Mbps data transfer rate. All USB 2.0 compatible products must implement the High Speed mode. The latest version is the USB 3.0 which adds an additional super speed mode with data transfer rate exceeding 4.8 Mbps. [5] The USB 3.0 standards was developed in response to the high speed demands from new super speed product developments.

High speed products include flash-based peripherals such as digital cameras and camcorders, flash memory drives, flash-based digital MP3 and video players, to mention a few. Another area where high speed is essential is when the interface's performance dictates the requirements of the product. Most of the improvements for USB 3.0 from USB 2.0 are done on the Link and protocol layers. [7]

## 2.3.3 USB Technologies

As more products started incorporating USB ports in their designs, new applications emerged and lead to new innovations. USB On-The-Go (OTG) and Wireless USB technologies are the outputs of these innovations. There exists a situation when a device is required to be a Host at one point and a Device at the other. The OTG is responsible for this to happen. It provides arbitration mechanism that permits units to negotiate who

should be the Host [5]. The wireless USB permits devices to be connected via the radio interface but still appear to the host as if it was using the ordinary USB cable [4].

#### 2.3.4 USB Connectors

There now many connector types used to interconnect USB units. Originally, there were two standard types, type A and type B before Mini and Micro were added. Figure 3 show some of the USB connectors available today.



Figure 3: USB Connector Types (reprinted from Universal serial Bus [8])

Types of USB connectors from left to right are Micro-B plug, Mini-B plug (8-pin), Mini-B plug (5-pin), Standard-A receptacle, Standard-A plug, Standard-B plug (ruler in centimeters) [8].

#### 2.3.5 USB Communication

The communication between the host and devices is started by the host. It recognizes the connected slave devices at boot-up and assigns them each with a unique device-address to a function. As mentioned in section 2.3.1, a device can have more than one function – the compound device. Then, all devices send their particulars to the host. These include their speed, and type of data transfer, among others. This process is known as Enumeration and the same occurs whenever a USB device is connected to an active host

or USB network. The communication between the host and the device function takes place via a logical channel called a pipe. [4, 5, 8]

On each slave device there exist endpoints. They are unique points in the device which sources or receives data to or from the host, with a definite address associated with each one of them. A USB device can have a maximum of 32 endpoints, with 16 endpoints to the host controller and 16 from the host controller. [4, 8] Figure 4 illustrates the USB pipes and endpoints with endpoints residing on the device.




Figure 4: USB pipe and Endpoints [4, 8]

The two different categories of logical pipes are the stream and message pipes and they are dependent on the type of data transfer.

There are four types of data transfer mechanisms:

- Control transfer is used by the host to communicate to devices, usually when it
  is asking for configuration information or sending commands
- Interrupt transfer is used by host to inquire from the input/output devices if they require immediate attention from the host
- Bulk transfer is used for exchanging large quantities of data using all the remaining available bandwidth left by other forms of data transfer

• I sochronous transfer is used when data transfer is required in real time but with data loss tolerance. [4, 5, 8]

When the host has enumerated the device and the communication between the host controller and the devices' endpoint is established, the device presents its descriptors to the host. Descriptors are data structures containing the endpoint configurations and expectations from the host. There are series of descriptors through which the device expresses itself:

Device Descriptor – a data structure that gives the basic information about the device, normally the host uses this information to ask for more information and to determine which device drivers to load. Inside this structure there is another structure, the string descriptor that gives descriptive text about the device such as device name, manufacturer and serial number. Configuration Descriptor - a data structure that gives the functionality and operation of the device, a device can have more than one configuration and hence multiple configuration descriptors exist. [5, 6, 9]

Interface Descriptor – a data structure that gives the information about the endpoints supported by the interface, composite devices have as many interface descriptors as there are device functions. Endpoint descriptors is a data structure that gives the details about data transfer type, direction of data transfer, packet size, bandwidth requirement, and polling interval of the endpoint. Endpoint 0 has no descriptor since it is mandatory for all devices to support it. The contents of all the above mentioned descriptors are given in Table 1; the order in which the attributes are arranged in practice might not be the same. [5, 6, 9]

Table 1: Contents of typical USB descriptors (compiled from USB Complete [9])

Device Descriptor	Configuration Descriptor	Interface Descriptor	Endpoint Descriptor
Length	Length	Length	Length
Descriptor Type	Туре	Descriptor Type	Descriptor Type
USB Version No.	Total Length	This Interface	Endpoint Address
Device Class	Interfaces	Alternate Setting	Attributes
Device Protocol	This Config	No. of Endpoints	Max Packet size
Max EPO Size	Config Name	Interface Class	Polling Interval
Vendor ID	Attributes	Interface Subclass	
Product ID	Max Power	Interface Protocol	
Device Version No.		Interface Name	
String Descriptor			
Manufacturer			
Product Name			
Serial No.			
No. of Configurations			

Descriptors shown in table 1 are data structures with data elements given in their corresponding columns. The string descriptor is part of device descriptor as depicted in table 1. Some of the data elements of the descriptor are also data structures with data elements.

#### 2.3.6 USB Device Classes

Classes are used by the USB standard to put together devices and interfaces with the same characteristic. That is to say, devices and interfaces that request or send the same type of data are grouped into the same class specification [9, 275]. Each class is identified by a unique code called the Class code, which tells the functionality of a device. The operating system uses the code to load the device drivers. Class codes help device driver developers to produces device drivers without targeting a particular manufacturer, as long as device developers comply with the specifications of that class [8]. Table 2 shows the device classes and class codes.

Table 2: USB Device Classes (Edited print from Technical Introduction to USB 2.0 [8])

Base Class	Device Descriptor	Description
01h	Device	Audio
02h	Interface	Communication & CDC control
03h	Both	HID (Human Interface Device)
07h	Interface	Printer
08h	Interface	Mass storage
09h	Device	Hub
0Eh	Interface	Video
E0h	interface	Wireless controller

The details of design requirements for a particular device class are contained in its class specification. Attributes defined in a class specification may include: number and type of endpoints a class supports, formats of data to be transferred, and information on how data being transported will be used [9, 276-277].

# 2.3. 7 Advantages of USB Interfaces

Some of the features that have attracted embedded systems designers to USB standard include:

- Hot-pluggable: where input/output (I/O) devices can be connected to a computer while powered on
- Ease of use: no need to develop drivers for the I/O devices, devices are automatically configured
- Single connector type: all devices use the same socket type
- High performance: up to 480 Mbps data rate for USB 2.0 and 10 times that of USB
   3.0
- Three speed choices: match the I/O device speed with one of the standard speeds for optimal design
- The interface can support up to 126 devices
- Power source for low power devices
- Error detection and recovery: data is retransmitted when errors are detected to ensure reliable data delivery. [6,2]

The popularity of the USB standard is likely to spread rapidly since most of the leaders in chip manufacturing have joined the bandwagon. This has led to considerable reduction on the cost of SOC chips enabled with USB controllers. [5]

## 2.4 Inter-Integrated Circuit (IIC) Bus

The Inter-Integrated Circuit is a bidirectional 2-wire bus, designed by Philips Semiconductors, for inter-connecting integrated circuits (IC). The IIC bus, also written as I2C, is not only useful to ICs inter-connections, but it can also be used to facilitate communication between components linked via a cable. [10]

#### 2.4.1 Features of IIC Bus

The IIC bus has features that make it stand out from other interfacing methods for some application. The characteristics of IIC include:

- Two-wire bus; the Serial Data line (SDA) and Serial Clock Line (SCL)
- All devices connected to the bus are assigned unique addresses and are accessible via software using master/slave relationship
- Many masters can be accommodated on the same bus in which case collision and arbitration is employed to prevent data corruption, should more than one master attempt to initiate data transmission at the same time
- Supports up to four serial, 8-bit oriented, bidirectional data transfer modes:
  - Standard mode of up to 0.10 Mbps
  - o Fast-mode of up to 0.40 Mbps
  - o Fast-mode plus of up to 1 Mbps and
  - o High-speed mode of up to 3.4 Mbps
- On-chip filtering rejects spikes on the bus data line to preserve data integrity
- The limiting factor to the number of devices that can be connected on the same bus is only the maximum bus capacitance. [10] Figure 5 illustrates the connection of master and slave devices using IIC bus with two pull-up resisters (R<sub>p</sub>).




Figure 5: IIC-bus with one master and two slaves [10]

The two slaves send their responses to the master, via the SDA line, only when they detect their address from the data packet sent by the master. The master provides the clock signal to the responding slave on the SCL line and at the end of the data transmission, the clock is removed. [11]

#### 2.4.2 The IIC Bus Protocol

The data between devices connected on the bus is carried by the SDA and SCL wires which are connected to supply voltage with resistors, as illustrated in figure 5. Devices connected to the bus, each has a unique address that is used to contact it. The interconnected devices can be transmitters and receivers or they can also be taken to be masters or slaves during data transfers. A master is responsible for initiating the communication and generation of the clock signal on the bus. The clock signal aids the data exchange between connected devices. [10]

The device to which the data is addressed is called the slave. All other devices to which data is addressed are considered to be slaves. On the other hand, a transmitter is known to be the device that sends data to the bus, and the device that receives data from the bus is the receiver. [10]

### 2.4.3 IIC Bus Used as an Interface

It is possible to connect embedded systems to a computer using IIC bus. At this point, the IIC bus is referred to as an interface other than a bus. One of the ways to connect IIC lines to a computer is by using its parallel port pins, but a bit-banging driver is required for the implementation of simple IIC master device [11]. The downside of this approach is its unreliability and risk of damaging the computer with electronic discharge or incorrect external line connections [11].

#### 2.4.4 IIC Bus Data Format

The first byte after a start condition of an IIC data transfer consists of a 7-bit slave address and a direction bit which differentiates between read and write (R/W). When R/W is = 0, the master transfers data to the slave, whereas when R/W = 1, the master receives data from the slave. The data is transferred with most significant bit first (MSB) as shown in figure 6. The acknowledgement bit (ACK) is sent to the slave after each byte of the ninth SCL clock. The start and stop conditions are generated by the master. A start condition is a high-to-low transition on the SDA line while SCL is high whereas a stop condition is low-to-high while SCL is high. [10]




Figure 6: Data transfer on the IIC-bus (Reprinted from I2C interface [11])

The IIC standard supports two addressing modes, the 7-bit and the 10-bit. The 7-bit addressing format is the one illustrated in figure 6. The 10-bit addressing format is introduced by a leading '11110' after the start condition [11]. It uses the last two address bits of the first byte plus the 8-bits of the second byte [11].

## 2.5 Serial Peripheral Interface (SPI)

The serial peripheral interface is a bus and a protocol that was developed by Motorola and later adopted by other players in industry [12]. It is a 4-wire serial communication interface used to establish full duplex communication between controllers and peripherals. [12] The SPI uses Master/Slave mode of communication and the master initiates the data transfers. The master generates the clock to support the synchronous communication with the slave or slaves. Like the IIC-bus, multi-master is possible with SPI but rarely

implemented [12]. The common configuration is one master and many slaves with a special signal to select individual slaves.

The SPI bus supports up to 10 Mbps data transfer and due to its high speed, it is the ultimate choice in applications where speed is critical. Some of the areas where SPI is the dominant interface bus include: converters such as Analog-to-Digital Converters (ADC) and Digital-to-Digital Converter (DAC), memory modules such as EEPROM and FLASH, sensors such as temperature, pressure, gyroscopes, acceleration sensors, and USB controllers.

[12]

#### 2.5.1 Data Transmission

To facilitate communication, SPI protocol specifies four logic signals. Two are data lines and the other two are control lines:

- Master Out Slave In (MOSI) a data signal generated by master and received by the slave
- Master In Slave Out (MISO) a data signal from the slave and received by the master
- Serial Clock (SCLK) a control signal generated by the master for synchronizing data transfers between the master and the slave
- Chip Select (CS) or Slave Select (SS)- control signal generated by the master to choose between the slave devices and it is an active low signal. [12, 13]

Figure 7 illustrates the master/slave relationship in the SPI protocol implementation. As mentioned in section 2.5, there can be one master and many slaves. Signal lines MOSI, MISO and SCLK are common to all slaves and CS line is separate for each slave as it is used to select between them.




Figure 7: SPI Master/Slave

The master always starts the transaction and supplies the clock to the slave(s). The master selects the desired slave by setting the CS line to low, waits for some time if necessary, and then issues the clock pluses. Only the slave whose chip select has been activated responds but the rest iginores the clock signal, allowing for single slave at a time. When the session is over, the chip select is set to high state and another one is set low in a mult-slave communication. Bi-directional communication is supported by the master reading the MISO line at the same clock cycle as slave reads MOSI line.

#### 2.5.2 Advantages of SPI

The serial peripheral interface has certain benefits that make it a favorite to some applications. The most significant include:

- Support for bi-directional (full duplex) communication
- High data rate
- Unlimited word length for the bits transferred
- Simple hardware interfacing
- Lower power consumption compared to IIC
- Lack of precision oscillator
- One "unique" bus signal per device. [12, 13]

SPI is a popular standard for interfacing the digital sensor and RF modules with microcontrollers or embedded systems in general.

## 2.5.3 Disadvantages of SPI

The SPI interface is unsuitable to use for some applications. Some of the downsides of SPI include:

- Requires more pin on IC packages than IIC
- No in-band addressing out-of-band chip select signals are required on shared busses
- No hardware flow control
- No slave acknowledgement
- Without a formal standard, validating conformance is not possible
- Can only be used for short distances unlike RS232 [12, 13]

For most of the application where SPI is favored, the benefits it offers over-shadow its drawbacks. But its lack of formal standard is a really disturbing defect.

# 3 Wireless Technologies

### 3.1 Overview

Wireless technology involves the techniques and standards that govern the sending and receiving of information between devices using air interface. Unlike the interfaces mentioned in chapter 2 which require physical connection, wireless communication transmits information by means of electromagnetic waves. The information to be sent is not always in the form suitable for transmission should be transformed to meet the characteristic of the transmission channel at the transmitter and then back at the receiver.

The process by which information is translated to a form that meets the requirements of the transmission channel is called modulation. There are different methods of modulation, named according to the parameter of the carrier signal they use during the translation. The carrier signal parameters are: amplitude, frequency and phase and the corresponding modulation methods are amplitude modulation, frequency modulation and phase

modulation respectively. During modulation, the parameter of the carrier signal in question is made to change with the amplitude of the information signal. The frequency of the carrier is always much higher than that of the information signal.

Modulation is necessary to be able to conform to regulations governing the use of the frequency band and bandwidth. All users of wireless or radio communication have a portion of the frequency band assigned to them and they must work within their boundaries. An example is an FM radio that broadcasts at 88.8 MHz, has to use frequency modulation to shift the information signals, at low frequency, to 88.8 MHz frequency. The receiver demodulates the signal - the reverse of modulation, to recover the original information.

## 3.2 Radio Frequency Spectrum

Radio spectrum is the part of the electromagnetic spectrum corresponding to the radio frequencies. Radio frequencies are frequencies lower than around 300 GHz [15]. The radio spectrum is divided into parts which are assigned to different radio transmission technologies and applications. The division is based on the frequency's wavelength and suitability for communication application [16]. The frequency band is a section of the radio spectrum which is set aside, in form of channels or bands, for a particular purpose as illustrated in figure 8. There are governments and institutions with a task of overseeing the allocation and use of the radio frequencies. There are regulations in form of standards to be followed by users to mitigate interference.




Figure 8: The Radio Spectrum (Reprinted from Electromagnetic spectrum [15])

The illustration in figure 8 also shows the frequency bands right from Very Low Frequency up to Infra-red and visible light. Moving from left to right, the attenuation of signals by atmosphere increases and this reduces the distance between the communicating devices for the information signal to be recovered.

# 3.3 Industrial, Scientific and Medical Band (ISM)

The ISM bands in the early days were meant to be used for industrial, scientific and medical purposes but now a common place for communication applications. There are several communication protocols that have been developed to utilize the advantages offered by the ISM bands. The fact that ISM bands are reserved internationally and are exempted from license, makes them attractive to developers of devices that must universally inter-operate. Some of the protocols utilizing the ISM bands include: Bluetooth, ZigBee, Wi-Fi and Dash7. The ISM bands are defined by the International Telecommunication Union Radio communication (ITU-R) but laws governing their use differ from country to country [16].

The original intended uses of the ISM bands were applications such as Radio Frequency Identification (RFID) devices, lighting, microwave ovens, low power audio, video and data links, to mention a few. The communication devices that operate in ISM bands must tolerate interference from other ISM equipment. For that matter, licensed operations are

discouraged from this band [16]. Some of the other reasons that make ISM band attractive include: relatively low frequency which makes it appropriate for mobile / nomadic communications and the global availability, which offers a rare opportunity for manufacturers to take advantage of the economies of scale that come with operations in a worldwide market. [16]

### 3.4 Bluetooth

Bluetooth is a wireless technology which was developed by Ericsson, with intentions of replacing the cables connecting handheld and or fixed electronic devices [17]. It operates in 2450 MHz band of the ISM bands. The Bluetooth, like all other wireless technologies operating in the ISM band, is required to stand radio interference from other devices. To be able to tolerate interference and fading, Bluetooth deploys radio frequency-hopping spread spectrum technology [17, 18]. This technology prevents more than on device from transmitting on the same frequency at the same time. Frequency-hopping is normally employed when up to eight devices are connected at the same time [18]. The other technique for minimizing interference is by transmitting low power signals difficult to intercept by other systems in the same vicinity.

### 3.4.1 Interfacing PC with Bluetooth

The Bluetooth technology can be used to interface embedded systems with a computer. Some computers, especially laptops, are embedded with the Bluetooth radio already. The Bluetooth USB dongle and Bluetooth wireless PC cards are also available to enable device designers to interface Bluetooth devices with computers [18]. The main focus of the Bluetooth wireless technology was to address the need for robustness, low power and low cost [17]. This concept serves well the requirements of handheld devices, which must consume low power and be cheap at the same time.

Similar to wired interfaces, such as USB, SPI and IIC, Bluetooth devices use a masterslave relationship to communicate. The master device can interact with up to seven Bluetooth devices within a network called a piconet. Like USB On-The-Go, Bluetooth master and slave devices can also switch roles. [18] When there are more than two Bluetooth devices in the network, the master selects the slave to communicate with. Typically, the master uses small time slots to communicate to all slaves in a round-robin style [19].

# 3.4.2 Versions of Bluetooth Specifications

There are mainly three versions of Bluetooth specification in use: the Bluetooth Low Energy Wireless Technology, the Bluetooth High Speed Technology and the Enhanced Data Rate [17]. The Bluetooth Low Energy Wireless Technology is the latest version of all; it was released on 6<sup>th</sup> July 2010. This version was designed to consume just a fraction of the power taken by Classic Bluetooth radio, which is good news for small devices powered on coin-cell batteries. [17] The main benefits of the Bluetooth low energy wireless technology include:

- Ultra-low peak, average and idle mode power consumption
- Ability to run for years on standard coin-cell batteries
- Low cost
- Multi-vendor interoperability
- Enhanced range. [17]

The predicted benefactors of this technology are devices such as watches and toys which can now be easily enhanced with the Bluetooth wireless technology. Other applications include those that are already enabled with Bluetooth technology in areas such as sports and fitness, health care, human interface (HIDs) and entertainment devices. [17]

The Bluetooth High Speed Technology offers enhancement to the core specification to produce a robust powerful wireless connection. This technology capitalizes on features such as:

- Power Optimization
- Improved Security

- Enhanced Power Control
- Lower Latency Rates [17]

The Enhanced Data Rate is an advanced short-range wireless technology useful and easier in connecting Bluetooth devices. The technology makes pairing of the Bluetooth devices much easy. The benefits of the enhancement to core specification include:

- Lower Power Consumption Reduced power consumption means longer battery life in devices such as mice and keyboards
- Improved Security For pairing scenarios that require user interaction,
  eavesdropper protection makes a simple six-digit passkey stronger than a 16-digit
  alphanumeric character random PIN code. The Enhanced Data Rate also offers
  "Man-in-the- Middle" protection that in reality eliminates the possibility of an
  undetected third party intercepting information.
- Near Field Communication The pairing enhancements provided by the enhanced data rate enabled the use of near field communication (NFC). [17]

## 3.5 Infrared

The Infrared (IR), as shown in figure 8, is a light wave below the visible spectrum. The human eye is unable to see and/ or interpreted infrared light, but can be "felt" in form of heat [17]. IR is produced from several sources and objects including human bodies, sun and all hot objects [20]. The fact that infrared can be produced cheaply, and suffers no interference from electromagnetic waves – a high ranking source of interference communication systems, are some of the advantages of using IR. The challenge encountered when using IR is differentiating useful IR from that coming from other sources. This problem is overcome by employing some type of coding. IR can be generated in pulses at some frequency and IR receivers are then tuned to detect pluses at that frequency [20]. This technique is used in many remote controls.

The IR can be used by devices to communicate with a computer having an infrared port (commonly known as IRDA port) or a USB port. If the computer has only the USB port, a

USB-Infrared converter or an infrared add-on to the motherboard would be is required. The information to be transmitted is coded, by use of amplitude shift keying (ASK) for example, and then transmitted over IR wave. The receiver decodes the information and passes it to the computer for interpretation and action taking. The IRDA, mentioned above, is an acronym for InfraRed Data Association – a transmission standard for two-way wireless infrared data communication. [20]

The advantage of using IR in communication system is because it is cheap to build into a device and is fairy reliable. The main drawbacks for IR-based systems are the line of sight, in which communicating devices have to point at each other to exchange information which also limits the range, and their support for only "one to one" form of communication. [17]

# 4 Sensor Technology

## 4.1 An Overview

A sensor is a device that converts a physical quantity, such as temperature, into a signal that can be read by an observer or measured by an instrument. Sensors are of two kinds, passive and active. Passive sensors do not require some form of external power supply to give an output signal, whereas active sensors use the external energy source to produce an output signal. Furthermore, sensors are either digital or analog. Analogue sensors give a continuous output signal usually proportional to the physical quantity being measured. On the other hand, digital sensors produce discrete output signal representing a binary number which can be interpreted by a microprocessor.

# 4.2 Sensor Terminology

There are a number of terminologies associated with sensors that must be understood before they can appropriately be applied. The definition of some of the terminologies might, differ in some way, from sensor to sensor and depending on the quantity being measured, but the big picture is the same. The knowledge about the common sensor terminologies is useful, since sensor datasheets are always littered with such terms from which a sensor suitable for an application at hand is identified. The next three paragraphs explain the commonly encountered terms during sensor selection.

Sensor sensitivity in general terms, gives the minimum input of physical parameter needed to create a detectable output change. Sensor sensitivity can also be looked at as the input parameter change required to produce a standardized output change or an output voltage change for a given change in the input parameter. In many data sheets, sensitivity error is also given which is none other than the deviation of the measured results from the expected value. [21]

The range of the sensor gives the maximum and minimum values of the applied parameter that can be measured [21]. An example is an angular rate sensor with range of -300 to 300 degrees/second (°/s) and corresponding acceleration range of -6 to +6 g. It is also possible to have non symmetrical ranges; an example is an LM35 precision centigrade temperature sensor with the range of -55°C to +150°C. The dynamic range on the other hand, tells the total range of the sensor from minimum to maximum [20].

The Precision of the sensor gives the level of confidence that the sensor will give the same correct results if the same quantity is measured a number of times. However, in real life, the sensor results can hardly be the same on every measurement, the output falls within a range of values distributed in a behavior relative to the correct value [21]. Resolution of the sensor, on the other hand, tells the smallest detectable incremental change of input quantity that can be detected in the output signal. The resolution is either expressed as a proportion of the reading or in absolute terms [21].

The accuracy of the sensor is the ratio of the highest deviation of the value represented by the sensor to the actual value. The expression for the accuracy can be as a percentage of full scale or in absolute term. Also the offset error of a sensor is the value at the output of the sensor at a time when there should be zero value. [21]

The linearity of a sensor is determined from its sensitivity over its range. If the sensitivity is not constant, then the term nonlinearity is used which is the magnitude by which the output deviate from the actual behavior over the full range of the sensor. The sensor is said to be linear if the change in the output depends on the change in the measured quantity. On the other hand, dynamic linearity of a sensor tells the ability of the sensor to follow rapid changes of the input quantity. Response time of a sensor is the time required for the sensor output to change from previous state to a final value within a tolerance band of the correct new value. [21]

#### 4.3 Acceleration sensors

Acceleration sensors (or accelerometers) are electromechanical devices that produce a voltage proportional to the acceleration of the object on which they are attached. There are two main types of accelerations to measure using the acceleration sensors: the static and dynamic acceleration. Static acceleration is related to the earth's pull on the device, whereas dynamic acceleration involves the movement and vibration of the device [22]. The mechanism behind which the accelerometer is able to measure the change of speed lies on the tiny micro-structures, inside the sensor, that are bent by momentum and gravity [23].

When an object, on which the accelerometer is attached, experience any form of acceleration, the micro-structures are bent by the same proportion which, in some way, is translated into a measurable electrical signal. The tiny micro-structures, depending on the technology employed, is part of a capacitor plates, a resistor or an electrochemical servo. It is these attachments that are used to measure the extent of the acceleration. [23]

There are a number of ways through which accelerometers are categorized, these include: their output type, sensing method, manufacturing technology, and other properties. Under

output type, there are analog and digital accelerometers. The analog, as the name suggests, produces a voltage at the output proportional to the type of acceleration, while digital types have pulse width modulated (PWM) waveform, IIC, or SPI output. On the other hand, acceleration sensors are classified as capacitive, used for tilt and vibration, piezoelectric – used for vibration and shock, piezoresistive, used for tilt and vibration, and electromechanical servo, used for tilt sensing. [22]

Accelerometers find applications in many areas and industries, and are used for activities such as:

- Self-balancing robots
- Tilt-mode game controllers
- Model airplane auto pilot
- Alarm systems
- Collision detection
- Human motion monitoring
- Leveling sensor, inclinometer
- Vibration detectors for vibration isolators
- G-Force Detectors [23]

The accelerometer is capable of measuring acceleration in three axes; x-axis, y-axis and z-axis. The sensors are made to be single-axis, double-axis or tri-axis, the choice of which is dictated by the application. Figure 9 illustrates the three axes that an acceleration sensor can measure on a robot.




Figure 9: The three axes an acceleration sensor can have (Reprinted from Sensors [23])

The accelerometer is subjected to gravitational acceleration ( $g = 9.81ms^{-2}$ ). It is advisable to use more than one axis to best detect imbalance on the object to which the accelerometer is attached. Actually, acceleration sensors are rated in terms of g, ratings such as 2g, 3g, and xg are commonly used, where x is an integer. The resultant acceleration of an object is calculated as follows:

• single-axis acceleration sensor:

o 
$$acceleration_max = \sqrt{x^2} = x$$
 (1)

• 2-axis acceleration sensor:

o 
$$acceleration_{max} = \sqrt{(x^2 + y^2)}$$
 (2)

• 3-axis acceleration sensor:

$$\circ \quad acceleration\_\max = \sqrt{(x^2 + y^2 + z^2)} [23]$$
 (3)

Equation 1, 2 and 3 are useful in applications where the exact acceleration of the object on which the sensor was attached is desired.

# 4.4 Gyroscopes

Gyroscopes are devices that convert rotational velocity into a signal that can be understood by an observer or measured by an instrument. The rotational velocity can be in one, two, or three axes and the resultant velocity is found using similar approach as for

accelerometer seen in section 4.3. The different types of gyroscopes, in some way, evolved from the traditional mechanical gyroscope which is essentially a spinning wheel or a disk whose axle is free to take any orientation [23]. The difference between types of gyroscopes lies on the physical property being exploited to detect the rotational velocity about some axis. Based on that, three basic types of gyroscopes can be listed, they include: rotary gyroscopes, vibrating structure gyroscopes and optical gyroscopes [25].

Rotary gyroscopes use the law of conservation of angular momentum to maintain a constant orientation while spinning. The presence of rotations about a given axis in a device gives the device the ability to maintain its orientation, and measurement of its angular velocity is achieved due to the phenomenon of precession [25].

The vibrating structure gyroscopes are Micro-machined Electro-Mechanical System (MEMS) devices that use Coriolis force [25] to measure the angular velocity of a rotating object. The gyroscope contains a sensing element composed of a micro-machined mass, kept in continuous oscillation and capable of reacting, based on the Coriolis principle, when an angular rate is applied. The angular velocity of the system is detected, in both magnitude and direction, with the aid of differential capacitance produced by the set of sensing fingers mounted on different sides inside the sensing element. [25] These types of gyroscopes are available commercially since they can be produced in small sizes unlike the rotary type.

The optical gyroscope uses the principle of Sagnac effect to detect mechanical rotation. To benefit from the Sagnac effect, also known as the Sagnac interference, two beams of light are made to follow a square or ring trajectory in opposite direction. When the ring is rotated, one of the beams will travel longer distance than the other and both will not reach at the same time, hence a phase shift will occur. At the end of the path, the point of entry, a detector is placed to detect the phase shift between the beams. [24, 25] When the ring trajectory setup is mounted on to a device, the phase shift detected is in proportion to the angular velocity of the device. The trajectory is normally made of fiber-

optic cable which affects the size of the gyroscope and so is their application. Optical gyroscopes mostly find applications in naval and aviation where size is a non-issue.

There are some gyroscope specifications which have to match with the application for which the gyroscope is intended to serve. They include most of those mentioned in section 4.2 and some that are unique to gyroscope include:

- number of sensing axes this give the number and type of axes the gyroscope can sense
- shock survivability this tell the magnitude of force a gyro can withstand before failing
- bandwidth is the number of measurement that can be made in a second
- angular random walk is a measure of gyro noise and has units of deg/sec<sup>1/2</sup>
- bias is the output of the gyro when there is no rotation
- bias drift tells the variation of bias over time
- bias instability It represents the best bias stability that could be achieved for a given gyro, assuming that bias averaging takes place at the interval defined at the Allan Variance minimum [25].

Gyroscopes are specified by the number of axes in which rotational acceleration is measured, such as single, dual, or tri-axis. Three-axis gyroscopes are often implemented with a three-axis accelerometer to provide a full six degree-of-freedom (DoF) motion tracking system. [25] The gyroscopes are either analog or digital. The analog gives a continuous voltages proportional to the angular rate whereas digital give discrete output as a binary number representation of the angular velocity. Mostly digital gyroscopes use SPI or IIC interfaces to communication with the outside world. [25]

# 5 Hardware Design

#### 5.1 Overview

The hardware design consists of mainly two parts: the transmitter and receiver designing. But before the actual designing is started, it is important that a list of the characteristics of the final product is revisited and translated into requirements which work as the guide during the hardware components selection. The requirement which establishes the specifications are identified and are presented in section 5.2.

### 5.2 Requirements and Specifications

Some of the requirements that were identified from the verbal description of the project from my supervisor include:

- 1. the user should be able to control the PowerPoint slides remotely
- 2. the user should have no physical connection (or contact) with the computer
- 3. when the user's arm is twisted (or rotated) to one direction the slide should move forward and backward when the arm rotates in the opposite direction
- 4. the component attached to the user's arm should be small with such a size that it can be hidden under the sleeve.

It is now clear that wireless communication between the user and the computer is required and also a motion sensor to detect the movement of the arm is inevitable.

The main components of the WGPC are illustrated in figure 10. The transmitter consists of a sensor, a microcontroller, an RF transmitter and an antenna. The receiver components include a USB interface, a microcontroller, an RF receiver and an antenna.




Figure 10: The WGPC block diagram

The sensor or transducer converts the motion of the human arm into electrical signals; the signals are filtered and processed by the microcontroller to retrieve the intelligence. The extracted intelligence, from the signal, is passed on to the RF transmitter for modulation and transmission. At the receiving end, the receiver's antenna intercepts the radiated signal wave; the RF receiver detects/demodulated it and passes it to the microcontroller for filtering and manipulation. The microcontroller reconditions the signal to a form fit to control the power point slides. Finally, the signal is sent to its mission, via a USB interface and the computer's USB port to the computer or operating system to be particular.

### 5.3 Transmitter Design

The transmitter consists of all the components on the transmitting side, that is to say, the sensor, microcontroller and the RF transmitter. The design began with the selection of the sensor, a microcontroller and radio frequency (RF) transceiver chip. The criteria on which the choices were made are explained in sections 5.31, 5.3.2 and 5.3.4.

#### 5.3.1 Sensor Selection

The project required a sensor capable of detecting the rate of change of angular acceleration of the human arm. There were two possible choices of sensors: the acceleration sensor or a gyroscope. A gyroscope was chosen over acceleration sensor

because it required no complex calculation to get the angular rate of change of velocity from the measured results. Complicated computation would complicate the choice of the microcontroller. The gyroscope is straight forward; the output is a representation of the rate of change of angular velocity.

The second task was to choose between analog and digital gyroscope. My choice here was corrupted by a promise to get some free samples from VTI Technologies by my supervisor. So I went for digital gyroscope since no other type was present on VTI's online store - then. From the project specifications, it was clear that detecting angular rate is in one direction, this concluded to a single-axis digital output gyroscope. VTI's SCR1100-D04 single axis gyroscope with digital SPI interface was a good candidate for the job. It has features such as:

- ±300 °/s angular rate measurement range
- Angular rate measurement around X axis
- Angular rate sensor exceptionally insensitive to mechanical vibrations and shocks
- Superior bias instability for MEMS gyroscopes (<1°/h)</li>
- Digital SPI interfacing
- Enhanced self-diagnostics features
- Small size 8.5 x 18.7 x 4.5 mm (w x I x h)
- Temperature range -40 °C...+125 °C.

The advantages of using a digital gyroscope was that there were no need for an analog-to-digital converter (ADC) in exchange for more microcontroller pins and time spent programming SPI to get the results. After spending a number of days interrogating the gyroscope's SPI for angular rate in vain, I switched to LPR430AL analog gyroscope from STMicroelectronics. The analog gyroscope requires an ADC and anti-aliasing filter for restricting the signal bandwidth so that the sampling theorem is respected. Fortunately, I needed no designing anti-aliasing filter since it was already integrated in the sensor. The features of LPR430AL analog gyroscope include:

- ±300 °/s analog gyroscope dual-axis pitch and roll
- 2.7 V to 3.6 V single-supply operation
- Wide operating temperature range (-40 °C to +85 °C)
- High stability over temperature
- Analog absolute angular-rate outputs
- Two separate outputs for each axis (1x and 4x amplified)
- Integrated low-pass filters
- Low power consumption
- Embedded power-down
- Embedded self-test
- Sleep mode
- High shock and vibration survivability.

The switch to the analog gyro was not necessary because it was not possible to extract any data from the digital type, but I wanted to spend as less time as possible since I was proving the concept. Actually, it was no critical having accurate results to have the project working which the digital would give at expense of more programming time.

#### 5.3.2 Radio Frequency Transceiver Chip Selection

The task of selection was more of verification than choosing. For purposes of prototyping, the CC2500 module, used for school projects, looked sufficient for the job. Though that was true, there was a need to verify that it had the features needed for this particular project. From the data sheet, some of the features that were relevant to the task at hand included:

- 3.9 V Max Supply voltage
- High sensitivity (–104 dBm at 2.4 kBaud, 1% packet error rate)
- Low current consumption (13.3 mA in RX, 250 kBaud, input well above sensitivity)
- Programmable data rate from 1.2 to 500 kBaud
- Frequency range: 2400 2483.5 MHz ISM frequency band
- OOK, 2-FSK, GFSK, and MSK supported (On and Off Keying, Frequency Shift Keying, Gaussian FSK and Minimum Shift Keying)

- Efficient SPI interface
- Programmable channel filter bandwidth
- Optional automatic whitening and de-whitening of data.

The points to note here are the supply voltage, the 24 GHz ISM band, modulation methods, the baud rate, SPI interface, and data whitening and de-whitening. These features needed to be considered while choosing the microcontroller. Fortunately, most of them are catered for by the transceiver hardware itself. Something that must be remembered is the 3V supply and SPI interface. The rest are configured via software.

#### 5.3.3 Microcontroller Selection

The choice of the microcontroller was influenced by the sensor's requirements and that of the RF transceiver module. It was clear that the microcontroller had to support SPI protocol, inbuilt analog to digital converter and had to have at least two ports. For the prototype I decided to use the Programmable Systems on Chip (PSoC) boards available in the laboratory. The remaining task was to select the microcontroller series that met the above requirements. It was found that CY8C29466-24PXI from Cypress Semiconductor was suitable for the job. Some of the features considered for its suitability included:

- 3.0V to 5.25V Operating Voltage
- Up to 14-Bit ADCs
- Programmable Filters and Comparators
- Multiple SPI Masters or Slaves
- 25 mA Sink on all GPIO (General Purpose IO)
- Up to 12 Analog Inputs on GPIO
- Four 40 mA Analog Outputs on GPIO.

The PSoC board was operated on 5V supply. Yet the sensor and the transceiver use 3 Volts. There should be a way to generate 3 V from 5 Volts. There were two alternatives; the first one was to redesign the PSoC board to make it operate on 3V, which would take some time designing and testing. The second was to use some form of voltage translation and regulation. I took the latter as the transceiver had the translator already designed and I only needed to design one for the gyroscope.

A voltage translator can be a two-way or one-way translator. The two-way translator allows two devices, operating at different voltage levels, to communicate without knowing the level differences. It inputs one voltage level and output the other in both directions. This chip was useful since both the gyroscope and the transceiver have bi-direction interaction with the microcontroller.

# 5.3.4 Final Transmitter Design

The on-chip modules, such as ADC and SPI interface, needed to be configured via the graphical user interface of the microcontroller's Integrated Development Environment (IDE). It was the PSoC Designer the starting point for the final design. Some on-chip modules have special ports to which they can be mounted. For example, the ADC could only be configured on port0 with its input on pin 1. Figure 11 shows the placement of the ADC and the SPI modules on chip level design. The analog input was connected to ADC input through a programmable gain amplifier (PGA) module. The ADC module took two analog blocks, one for the timer and the other for the counter, and one digital block for the ADC itself. The outputs and inputs were routed to and from the port pins respectively, as shown in figure 11.




Figure 11: The chip level design for the transmitter

The output of the sensor module is channeled to pin1, since at this point it is known that the ADC feeds from port0\_0. Figure 12 shows the components that make up the sensor module. The control signals from the microcontroller are level shifted by the voltage translator before being feed to the gyroscope and the responses from the gyroscope follows the opposite direction back to the microcontroller. The schematic diagram for the sensor module is given in appendix 1.




Figure 12: Components of the sensor module

The microcontroller supplies 5 Volts to the module which is converted to 3.3 volts before being feed to the gyroscope. Figure 13 show an already made sensor module with the gyroscope and the necessary filters. This break-out board is from STMicroelectronics. The already made module was used for trouble shooting at the testing phase to isolate hardware flaws from those from software. A similar arrangement was needed for the break-out board to shift the signal levels and to generate the 3.3 volts supply. A board was designed, with the shifter and a regulator, into which the break-out was plugged.




Figure 13: Gyroscope module from STMicroelectronics

The radio transceiver consists of a voltage regulator, voltage translator and an RF transceiver module as shown in figure 14. The module was designed to be plugged into a 10-pin port of the PSoC board. Figure 15 shows the complete assembly of the transmitter with Liquid Crystal Display (LCD) included for debugging purposes during the testing phase of the project development. The PSoC board has three ports, port\_0 to port\_2. The port assignments are: sensor module to port\_0, radio transceiver to port\_1 and LCD to port\_2. The microcontroller is programmed via the MinProg port indicated in figure 15.




Figure 14: The Radio transceiver module

The radio transceiver module was adapted to the PSOC board via a 10-pin port connector. The 5 volts power supply from the PSOC board was converted to a 3.3 volts supply using a 3.3 volts regulator. The voltage translator is a two-way level shifter between 5 volts from the microcontroller and the 3.3 volts to the RF module.




Figure 15: The complete setup of the transmitter with LCD

The final setup of the transmitter was comprised of the sensor module located onto port0, radio module onto port1 and LCD onto port2. The PSOC board could be power through a MinProg port by the programmer or through the 2-pin port by a battery power source.

### 5.4 Receiver Design

The receiver consists of all the components on the receiving side of the system. Similar to the transmitter, selecting components to be used in designing the receiver was the first on the task list. In addition to the components used in the transmitter design, there was an extra task of identifying the best way the receiver would communicate with the computer. The transceiver chip chosen for the transmitter qualified to work at the receiving end as well but the microcontroller did not.

# 5.4.1 Computer Interface Selection

There are at least four methods that can be used to interface an embedded device with a computer, discussed in sections 2.2, 2.3, 2.4 and 2.5. Interfaces to external devices need device drivers to aid the interaction between the device and the operating system. Apart from the USB interface, the rest involved development device drivers – a complex task that should be avoided if possible. For this reason, the USB interface was chosen. The USB protocol has the drivers pre-installed on most of the operating systems, as mentioned in section 2.3. The best way out here was to design the receiver as a human interface device. The receiver should imitate the keyboard so that every time it is plugged into the USB port, the computer "thinks" it is a second keyboard.

Now that my controller looked like a keyboard, the next step was to make it behave like a keyboard. It should be used as if it has the arrow keys, like the keyboard, to be able to drive the PowerPoint slides back and forth. With the concept conceived, the remaining part was to choose a microcontroller with inbuilt USB controller, and later on design the descriptors for the USB keyboard.

### 5.4.2 Microcontroller Selection

The receiver's microcontroller, as mentioned in section 5.2, should have an integrated USB transceiver or USB controller and SPI interface module. The CY8C24894-LFXI microcontroller from Cypress Semiconductor had the features fit for the job. A voltage regulator was needed since the USB port supplies 5 Volts and yet the microcontroller and the transceiver operated on 3.3 Volts. The other alternative was to use the microcontroller in 5 Volts mode and install a voltage translator to support the communication between the microcontroller and the transceiver. The dark side of this move was the increased cost of the controller since the translator costs more than the voltage regulator. For the fact that the PSOC board with a USB support was selected, using voltage translator was the only way to go.

# 5.4.3 Final Receiver Design

The physical hardware design began with the chip level design to identify which port and pins would host what module. The receiver required one SPI and USB module (USB has no digital block) as show in figure 16. The SPI is for communication between the radio module and the microcontroller and USB module is for interactions between the computer and the microcontroller. The radio module was configured to port0 and its control signals were routed to corresponding pins shown in figure 16.




Figure 16: The chip level design for the receiver

The PSoC board shown in figure 17 has up to five ports, one USB connector, and two humidity sensor. But only two ports are useful for the project; one for the radio module and the other for the LCD – used for debugging the software. Figure 18 shows the complete assembly of the PSoC board used for a receiver.




Figure 17: PSoC board with USB interface

The PSOC board with USB interface was designed with several I/O port connectors allowing support for more than one application. The microcontroller was programmed via a 5-pin connector.




Figure 18: The complete setup of the receiver with LCD

The RF transceiver module and the LCD were mounted onto a break-out board which was inserted into the ports of the microcontroller board. The LCD was included to aid software debugging. The USB connector is located under the board as shown in figure 18.

# 5.5 Tools and Equipment

The tools that were used during the design included both hardware and software and are listed against their contribution to the project development.

- The <u>PADS family software</u> were used to support schematic design, layout design and generation of the LMD files for the milling machine to produce the printed circuit board (PCB)
- The <u>Digital multi-meter</u> was used during trouble shooting of the hardware, I was important to know that each section of the circuit had power and it was of the right level
- The <u>LCD</u> was included t support software debugging, it is a handy tool when checking for sections of the code that do not execute
- The <u>FilterPro</u> was used for analog filter designing, these includes the anti-aliasing filters and power supply serge filters
- The <u>Matlab</u> is the tool for digital filter designing but no much digital filtering was done apart from a running average designed to reduce on the signal noise levels.

### 5.6 Design Challenges

The main obstacle I faced during the design process was soldering the gyroscope. Soldering manually a 4x5x1 mm Quad Flat No leads (QFN) packaged chip, was not "playing with a friend". I tried several pieces but could not get it right, reason partly being, wrong tools. Hot air soldering station at Electria saved me from frustration as I could melt the solder wire with ease. It was by no means easy to find the USB keyboard key-codes; there are many different key-codes as there are keyboard types.

# 6 Software Design

#### 6.1 Overview

The software part of the project involved two pieces of software; the transmitter software and the receiver software. The coding was done using the chip manufacturer's IDE, the PSoC Designer 5.0. There was interdependence between the hardware designing and software designing as some features of the hardware had to be implemented or configured in software. For example, the SPI module, USB module and ADC have to be configured on chip level first. This meant that some sections of the software had to be handled before the completion of the hardware design process.

### 6.2 Transmitter Software Design

The transmitter software controls data acquisition from the sensor, filters off noise to some level and initializes data lines. The control signals used to create a communication link between the microcontroller and the RF radio module are generated by the same transmitter software. Finally, it takes the responsibility of passing data to RF module for transmission. Some modules employed in the transmitter, as mentioned in section 5.3.4, are programmable, these include the SPI, LCD, ADC and PGA. The control signals, for the SPI module, are created using Light Emitting Diodes (LEDs) modules. The control is achieved through turning ON and OFF of the LEDs. Figure 19 illustrates the program flow used to produce the C language codes for the transmitter.




Figure 19: The Program Flow of the Transmitter software

The flow chart illustrates the main program modules of the transmitter software. When the program starts, it initializes all the local variables and the digital and analog modules or blocks before entering the forever loop. While in the loop, data from the ADC's register is read and compared to two local constants. If the outcome of the comparison is valid for the high limit, a forward command is packed and sent for transmission. If it is valid for the lower limit, a backward command is sent, otherwise an empty command is sent for to RF radio for transmission if none is valid.

The implementation of the flow chart in C language is given in appendix 2. The idea was to imitate a USB keyboard, the slides movement commands are the real Key codes for USB keyboard's arrow keys. For the forward command, 0x4F code is sent and 0x50 code is sent for the backward command. The command 0x4F is a representation of right arrow key and 0x50 is the left arrow key.

### 6.3 Receiver Software Design

The receiver software is responsible for aiding the reception of data by the RF module, processes it to extract the intelligence, and then coordinate its transfer to the computer. There are a number of activities handled by the software from the time the receiver is turn on to the time a slide is controlled remotely. Figure 20 shows the main tasks undertaken by the receiver software.

When the receiver is powered, variables and modules are initialized. Then, the USB operation is started and waits to be enumerated by the host computer. When the device is enumerated, endpoint 1 is loaded to allow data transfers between the device and the host computer. At the end of the above activities, the program enters a continuous loop from where data from the transmitter is waited for and read from receiver data-buffer. The data packet is opened to check its content. The first item to check from the received data is the address; the packet is dropped if it has a wrong address. The received command is loaded into the USB transfer buffer, the status of the endpoint is checked, and after receiving an acknowledgement the data is loaded to endpoint 1.

The implementation of the receiver program flow-chart in C programming language is show in appendix 3. The hidden detail of the above software design is the implementation of the report descriptors that was mentioned in chapter 2. Fortunately, there was no need to write data structures to implement them, as the PSoC designer 5.0 has a USB Setup Wizard, a graphical user interface (GUI) for designing USB descriptors. However, it is important to know the right parameters to feed into the wizard, otherwise the device may fail to be enumerated or work.




Figure 20: The Program Flow of the Receiver software

The flow chart illustrates the main program modules of the receiver software. After the initialization of the variables and hardware modules, the program enters a forever loop into which tasks such: data reading, data comparison and transmission are done.

Figure 21 shows a screen print of the GUI for the USB Setup Wizard with required descriptors clearly shown.




Figure 21: USB setup wizard user interface

It is important to mention the importance of changing the Product ID and Device release every time the descriptor is edited. When a USB device is plugged into the computer, the operating system loads its device drivers, after which the OS stores the Product ID and Device release number. The next time a device is plugged into the computer; the OS

compares the current Product ID and Device release number with the ones previously stored. If they match, the OS retrieves the previously installed drivers. Therefore, the changes are not recognized when the product ID and device serial number are not changed.

# 7 Testing

# 7.1 Testing Overview

Testing is an important stage of product designing as it helps the designer make an assessment on whether the designed piece of hardware or software works as expected. The testing involved hardware and software testing for both the transmitter and receiver as described in the next sections.

# 7.2 Transmitter and Receiver Hardware Testing

The Voltage presence and voltage levels were the baseline for testing the hardware. However, some hardware components could not be tested in isolation from the software as they were configured or implemented in software. Therefore, thorough hardware testing was done at the integration level, a point where both the hardware and software were made to interact. The main component that needed testing on the transmitter was the sensor module. The challenge was that of its dependence on control signals from the microcontroller. There are three control signals, the High-pass (HP), Self-Test (ST) and Sleep/Power-down (SLP). The High-pass (HP) signal controls the high-pass filter but it could be ignored at start.

When the two signals, ST and SLP are at low state (zero or ground), the sensor operates in normal mode. The ST, SLP and GND pins were connected to ground and VDD to +3.3 Volts - from a DC power supply. Pin X, the output from the sensor, was connected to the positive probe of a digital multi-meter and of course the other to ground. The digital multi-meter recorded 1.45 V when the sensor was left stationary. When the sensor was turned clock-wise, the reading increased by a magnitude proportional to the rate of turning and

decreased in a similar manner when it was turned anti-clock-wise. This was a good indication that the sensor was working properly.

It was necessary to test the ADC too and a test program was written to configure and display the ADC results on the LCD. When the sensor was rotated, the reading on the LCD was observed to be changing with magnitudes proportional to rate at which the sensor was turned. This was also a confirmation that the ADC was converting the sensor voltage as it was expected. To test the functionality of the RF module, a control receiver was configured to receive any radio wave transmitted on channel 0 and display its value on LCD. A test program was written that sent an up-counter value every second. When the units were powered - the transmitter and receiver, it was observed that the value on the receiver's LCD counted up every second – a proof for the proper functioning of the transmitter.

The receiver had two tests to make: the first one was to test its ability to receive data via radio link and the second was to test its USB interface. If it could be enumerated, that would mean that the USB interface was well configured. To start with, a program from the control receiver was loaded to the receiver with some adjustments to match its architecture. The same behavior of the counter value, seen earlier on the control receiver, appeared on the receiver's LCD.

To test the USB interface, the USB configuration shown in figure 20 was applied to the receiver. The receiver was then plugged into the USB port of the computer, a message was seen at the bottom of screen indicating the detection of a USB device. After a few seconds, a popup message indicated the installation of drivers for the connected USB device and later, another popup informed about the complete installation of the driver and readiness to use the hardware. All these messages indicated a successful enumeration of the receiver. At the end of the tests, it was clear that both the transmitter and receiver hardware were working as expected.

# 7.3 Transmitter and Receiver Software Testing

Testing the software is intended to uncover software bugs. A software bug refers to a mistake, failure or fault in the code that makes the computer program to give un-expected results or behavior. It is important, during testing, to design test cases that cover all subroutines in the program. All subroutines may not be executed at the same time, but they should execute at some point if bugs are to be detected.

The subroutines to test were: Initialization(), readData(), and the three decision-making in the while loop. The easiest way to tell if these routes execute was to place a printing function inside them, in that, once a routine is executed, some character is printed on the LCD. Other printing functions were placed in the selection sections and variables were created which would make the selections true, in sequence. When the program was loaded to the hardware and the hardware powered, it was observed that characters were printed on the LCD in their respective places as was expected. The same procedure was used to test the receiver software; the difference was the absence of the readData subroutine. The positive results confirmed proper executions of the selection sections and subroutines, for both the receiver and transmitter software.

The second part was to test the subroutines responsible for sending and receiving data via radio link. A counter variable, as was in the hardware testing, was created in the transmitter software, packed into the transmitter buffer and sent. The receiver was adjusted to print the received data on to the LCD. When the two modules were powered, an incrementing variable was observed on the receiver's LCD – a sign of good transmission and reception of data.

The third test was testing the imitated USB keyboard to control slide shows. Two buttons were configured on to the receiver; one representing the right arrow key and the second the left arrow key. The result would be, depending on the button pressed, slides should move left or right. When the receiver was powered and a button pressed, the slide moved

to the right and to the left when the other button was pressed. It was clear that the receiver had mimicked a USB keyboard as was expected.

# 7.4 Integration Testing

After testing individual components, it is necessary to check their behavior when they are connected together to form a system. If the result of this test is agreeable, then it is safe to say the product is completed. The testing began after editing the transmitter and receiver software off the test functions and variables. The transmitter and receiver were assembled to their respective positions, with the receiver's USB connector plugged into the computer's USB port. The transmitter was powered from 6 Volts battery assembly. A PowerPoint file was open on the computer to which the receiver was attached.

When the transmitter was rotated clockwise and anti-clockwise slowly, the slides did not move. But when the transmitter was rotated clockwise faster, the slides were seen moving forward and backward when it was rotated faster anti-clockwise. The rotation was within 180 degrees, and the transmitter was turned from 0° to 180° at a rate similar to that used to open book pages, fast. After a turn in a desired direction, the arm should be collapsed slowly in the opposite direction if more slides are required to be opened. The results were impressing, and the project was complete.

The concept of a wireless gesture-activated PowerPoint controller was proved feasible. The prototype was designed, implemented, operated and found to be in a complete working condition.

# 7.5 Future Developments

There is room for improvement on the side of energy saving, cost, and compactness. There are microcontrollers that consume less energy, are small in size and cheap at the same time. A microcontroller with an in-built RF module should be used in the project as it consumes less power and uses less space on the PCB. An example of such a system-on-chip (SoC) Microcontroller is nRF24LE1 for the transmitter and nRF24LU1 for the receiver

both from Nordic Semiconductor. Another alternative could be CC1110Fx for the receiver and CC430F613x for the transmitter, both from Texas Instrument.

To be able to save power, a transmitter should only transmit when there is data from the sensor. The idea of sending empty commands wastes energy and should be eliminated in future designs. The receiver, on the other hand, should go to sleep mode when there is no data being transmitted. A technique known as Wake-On-Radio (WOR) should be employed. When WOR is enabled, the controller stays in the low power mode and is woken up by a radio signal.

It would be good if the receiver had some form of memory where the presenter could store his or her slides. This would eliminate the possibility of carrying the controller but forgotten the USB stick hosting the slide shows. An additional feature where the user adjusts the sensitivity of the controller to the rate of rotation would improve the user experience. A button is the immediate choice for the implement the sensitivity to the controller.

### 9 Conclusion

The goal of the project was to design and implement a remote gesture activated PowerPoint controller. The project involved selection between different wireless technologies, sensors, interfacing technologies and microcontrollers. Consequently, gaining knowledge from areas such as interfacing technologies, wireless technologies, sensor technologies, electronic design, embedded systems programming were prerequisites to the project success. The choice of most of the components used in the project was influenced by the desire to use as many already available components as possible to have the concept proved.

The objective of the project was achieved; the prototype was successfully designed using the development boards available in laboratories. It is possible to move the slides forward by rotating the controller clock-wise as if opening book pages, and backward by rotating the controller anti-clockwise, as if closing book pages. Controlling the slide show by a simple imitation of opening a book is impressive. The fear, though, remains on the possibility of the audience to shift the attention from the content of the presentation to the art employed in giving it.

However, some improvements are necessary to the controller, to make it cheaper, smaller in size, consume less energy and above all more functional. The microcontrollers should be configured with wake-on-radio and wake-on-event to be able to save energy. Adding more functionality can be achieved by including an external flash memory on the receiver for storage of the slide shows. Addition of buttons onto the transmitter would allow for adjustable sensitivity.

### References

 Presenting Effective Presentations with Visual Aids [online]. Construction Safety and Health Outreach Program, U.S. Department of Labor May 1996, Washington, DC 20210

URL: http://www.osha.gov/doc/outreachtraining/htmlfiles/traintec.html Accessed 21 January 2011

2. Craig Peacock. Interfacing the serial/RS232 Port [online]. Pair Networks. Inc 1995 – 2011 Pittsburgh, USA.

URL: http://www.beyondlogic.org/serial/serial.htm. Accessed 21 January 2011

- 3. Microcontroller UART tutorial [online]. Society of Robots 2010 URL: http://www.societyofrobots.com/microcontroller\_uart.shtml
- Conrad J.M. Introduction to USB Development [online]. College of Engineering UNC, North Carolina USA, 2006 URL: http://www.coe.uncc.edu/~jmconrad/ECGR6185-2006-01/notes/USB.pdf. Accessed 28 January 2011
- Embedded USB a brief tutorial [online]. Computer Solutions Ltd 2011, Addlestone, England URL: http://www.computer-solutions.co.uk /info/Embedded\_tutorials/ usb\_tutorial.htm. Accessed 28 January 2011
- 6. Hyde John. USB Design by Example, second edition: Intel Press
- Ravencraft J, Rahman I. USB 3.0 Update, Developers Conference 2007 [Online]. USB Implementers Forum, Beaverton USA URL: http://www.usb.org/developers/wusb/docs/presentations/2007/ Ismail\_\_ Ravencraft \_-\_USB3.0.pdf. Accessed 31 January 2011
- 8. A Technical Introduction to USB 2.0 [online]. USB Implementers Forum, Beaverton USA URL: http://www.usb.org/developers/whitepapers/usb\_20t.pdf. Accessed 1
  - February 2011
- 9. Jan Axelson. USB Complete, second edition. Lakeview Research, 2001 Madison USA
- 10. I2C-bus specification and user manual Revision 03: NXP Semiconductors 2007, Eindhoven, Netherlands


URL: http://www.nxp.com/documents/user\_manual/UM10204.pdf. Accessed 6 February 2011


- 11. IIC: I2C Interface [Online]. telos EDV Systementwicklung GmbH 1997, Hamburg Germany.
  - URL: http://www.i2c-bus.org/i2c-bus/. Accessed 9 February 2011
- 12. SPI Bus Interfaces [Online]. Electronics Engineering Herald , Bangalore India 2006 URL: http://www.eeherald.com/section/design-guide/esmod12.html. Accessed 11 February 2011
- 13. SPI Interface Specification [Online]. VTI Technologies, Vantaa Finland 2005 URL: http://www.vtitechnologies.jp/documents/data\_sheet/ TN15\_SPI\_Interface\_Specification.pdf. Accessed 11 February 2011
- 14 John Neuhaus. Allocation of Radio Spectrum in the USA [Online]. URL: http://www.jneuhaus.com/fccindex/spectrum.html Accessed 16 February 2011
- 15 The Electromagnetic Spectrum [Online]. Sky Scan 2005: Alberta, Canada URL: http://www.skyscan.ca/the\_electromagnetic\_spectrum.htm. Accessed 16 February 2011
- 16 Industrial Scientific and Medical (ISM) Bands [Online]. Wireless Communication 2006 URL: http://wireless.per.nl/reference/chaptr01/dtmmsyst/ism.htm. Accessed 16 February 2011
- 17 Bluetooth Special Interest Group. More than just replacing cables [online]. WA2JXE Bluetooth SIG, Inc 2010: Kirkland, Washington USA URL: http://www.bluetooth.com/English/Technology/Works/Pages/default.aspx. Accessed 18 February 2011
- 18 C. Franklin, J. Layton. How Bluetooth Works [online]. Howstuffworks, 2011 Georgia USA URL: http://www.howstuffworks.com/bluetooth.htm. Accessed 18 February 2011
- 19 Pav Lucistnik. Bluetooth. FreeBSD Handbook 1995 -2011 URL: http://www.freebsd.org/doc/handbook/network-bluetooth.html. Accessed 20 February 2011
- 20 Wagner Lipnharski, Infrared Remote Control (Online). UST RESEARCH INC: Orlando, Florida USA URL: http://www.ustr.net/infrared/infrared1.shtml. Accessed 23 February 2011
- 21 Joseph J. Carr John M. Brown, Sensor Terminology; National Instruments Corporation 2010, Austin, Texas USA URL: http://zone.ni.com/devzone/cda/ph/p/id/227. Accessed 25 February 2011

- 22 Archana Yarlagadda, Accelerometer interface using PSOC. Cypress Semiconductor Corporation, 2009. California, USA URL: http://www.cypress.com/?docID=19786. Accessed 26 February 2011
- 23 Palmisono, Sensors Accelerometer. Society of Robots , 2011 URL: http://www.societyofrobots.com/sensors\_accelerometer.shtml. Accessed 26 February 2011
- 24 Marshall Brain. How Gyroscopes Work [online]. Howstuffworks, 2011 Georgia USA URL: http://www.howstuffworks.com/gyroscope.htm. Accessed 4 March 2011
- 25 Collicuttm. Gyroscope [Online]. SensorWiki.org; Quebec, Canada 2009 URL: http://www.sensorwiki.org/doku.php/sensors/gyroscope#gyroscope. Accessed 4 March 2011

# Appendixes

Appendix 1: WGPC Sensor Module Schematics and PCB





# Appendix 2: Transmitter C-Program codes

```
//C main for Radio Transmitter, Key codes are radiated
// depending on the value read from the Gyroscope
//-----
#include <m8c.h> // part specific constants and macros
#include "PSoCAPI.h" // PSoC API definitions for all User Modules
#include "PSoCGPIOInt.h" // PSoC API definitions for I/O interrupts
#include "rf.h" // The RF module API
                                   // Add this header to use the ftoa function
#include "stdlib.h"
// Function prototypes
void Initialization(void); // Initializes the application void readData(void); // Read the data from Gyro #define RF_CHANNEL 0 // Set radio channel to 0
// Size is defined as Payload + Dest_addr, but... use only payload size
#define PACKET SIZE 7
// Global variables
BYTE Tx_packet[PACKET_SIZE] = {0, 0, 0, 0, 0, 0}; // Initialize Transmitter buffer to 0
BYTE RF_channel = 0; // Variable for setting the channel
INT iData:
                                   // For storing ADC data
INT idata; // For storing ADC data

INT dataBuff[]= {0,0,0,0}; // Moving average filter buffer float dataSum = 0.0; // Average variable
BYTE Status_Reg;
BYTE rxData[16];
// Start of the main program
void main()
{
         Initialization ();
                             // Initialize all modules
         while (1)
                           // Forever loop
         readData();
                                   // Harvest data from the sensor
          if (dataSum <= (0-100.0)) // Check if negative angular acceleration
                   SleepTimer_SyncWait(512, SleepTimer_WAIT_RELOAD); // delay by a second
                  Tx packet[0] = 0x00; // Load zeros
                  Tx_packet[1] = 0x00;
                   Tx_packet[2] = 0x50; // Load left arrow key code
                  Tx_packet[3] = 0x00;
                  Tx_packet[4] = 0x00;
                  // Send packet via radio link
                  rf_sendPacket(Tx_packet, PACKET_SIZE);
                  SleepTimer_SyncWait(512, SleepTimer_WAIT_RELOAD); // delay by second
                  dataSum = 0.0;
                                                                                   // Reset variable
          }
```

```
else if(dataSum > 810) // Check if positive angular acceleration
       // delay by 1 second
       SleepTimer_SyncWait(512, SleepTimer_WAIT_RELOAD);
       Tx_packet[2] = 0x4f;
                                      // Load right arrow key code
       Tx_packet[3] = 0x00;
                                      // Load zeros
       Tx_packet[4] = 0x00;
       // Send packet via radio link
       rf_sendPacket(Tx_packet, PACKET_SIZE);
       SleepTimer_SyncWait(512, SleepTimer_WAIT_RELOAD);
       dataSum = 0.0;
                             // Reset variable
               }
       else
               // No angular acceleration
               Tx_packet[0] = 0x00; // Load zeros
               Tx_packet[1] = 0x00;
               Tx_packet[2] = 0x00;
               Tx_packet[3] = 0x00;
               Tx_packet[4] = 0x00;
               // Send packet via radio link
               rf_sendPacket(Tx_packet, PACKET_SIZE);
               }
       } // end of while
} // end of main
void Initialization(void)
{
       M8C_EnableGInt;
                                              // Enable Global Interrupts
       // Configure 512 Hz SleepTimer
       SleepTimer SetInterval(SleepTimer 512 HZ);
       SleepTimer_EnableInt();
                                              // Enable interrupt
       SleepTimer_Start();
                                              // start sleep timer
       //LCD_Start();
                                              // Initialize LCD
       // Initialize SPIM and the RF module
       SPIM_Start(SPIM_SPIM_MODE_0 | SPIM_SPIM_MSB_FIRST);
       SPIM_CS_Start();
                                              // Start SPI master chip select
                                              // Activate chip select
       SPIM_CS_On();
       // Initialize Motion Sensor control signals
       LED_Start();
                                      // Indicator light
       ST_Start();
                                       // Self-test bit signal
                                       // Set signal low
       ST_Off();
       SLP_Start();
                                       // Sleep mode control bit
       SLP_Off();
                                       // Set signal low
       //programmable gain amplifier
       PGA_Start(PGA_MEDPOWER);
       // ADC initialization
       ADCINC12_Start(ADCINC12_HIGHPOWER);
                                                      // Apply power to the SC Block
       ADCINC12_GetSamples(0);
                                                      // Have ADC run continuously
```

```
while(ADCINC12_flsDataAvailable() == 0);
                                                    // Loop until value ready
                                                    // Clear ADC flag
       ADCINC12_ClearFlag();
                                                    // Get ADC result
        iData=ADCINC12_iGetData();
// The RF module
RF_channel = RF_CHANNEL;
                                             // Set channel
rf_init();
                                             // Initialize radio module
                                             //Set radio channel
rf_setChannel(RF_channel);
} // end of initialization
void readData()
       INT dataTemp = 0; int j = 0;
       While (ADCINC12_flsDataAvailable() == 0); // Loop until value ready
       ADCINC12_ClearFlag();
                                                    // Clear ADC flag
       iData = ADCINC12_iGetData();
                                                    // Get ADC result
// moving average filter
       while(j < 3) {
         dataBuff[j] = dataBuff[j+1]; // Shift array backward
        j++;
        }
                             // Load current data onto the top of the array
       dataBuff[3] = iData;
        i=0;
       while(j \le 3) {
        dataTemp += dataBuff[j];
                                    // Add up the contents of the array
        }
       dataSum = dataTemp /4;
                                      // Compute average
}
       // end of readData
```

# Appendix 3: Receiver C-Program Codes

```
// C main line for the Receiver with USB interface
#include <m8c.h> // Part specific constants and macros
#include "PSoCAPI.h" // PSoC API definitions for all User Modules
#include "PSoCGPIOINT.h" // Useful pin definitions
#include "rf.h"
                // The RF module API
// Global variables
BYTE Rx_buffer[RF_BUFFER_SIZE];
BYTE RF_channel = 0;
// Function prototype
void Initializations(); // For initializing APIs
// Start of the main program
void main()
                           // Initialize Rx Packet variables
unsigned char packet_length = RF_BUFFER_SIZE, rssi = 0, lqi = 0, crc_ok=0;
Initializations(); // Initializes all modules
//Start USBFS Operation using device 0 and with 5V operation
USBFS_Start(0, USB_5V_OPERATION);
                                       // Start USB module
while(!USBFS_bGetConfiguration()); //Wait for Device to enumerate
//Enumeration is completed load endpoint 1. Do not toggle the first time
USBFS_LoadInEP(1, abRGPData, 8, USB_NO_TOGGLE);
while(1) // Forever loop
// Wait for and read data from the RF module
crc_ok = rf_getRxPacket(Rx_buffer, &packet_length, &rssi, &lqi, RF_WAIT);
             if(Rx\_buffer[2] == 0x4f) // Check if it is a right arrow key code
             abRGPData[2] = 0x4f; //Start moving the slide to the right
             while(!USBFS_bGetEPAckState(1)); //Wait for ACK before loading data
        //ACK has occurred, load the endpoint and toggle the data bit
              USBFS_LoadInEP(1, abRGPData, 8, USB_TOGGLE);
              abRGPData[2] = 0x00;
                                                //Reset buffer
             while(!USBFS_bGetEPAckState(1)); //Wait for ACK before loading data
              USBFS_LoadInEP(1, abRGPData, 8, USB_TOGGLE);
        SleepTimer_SyncWait(36, SleepTimer_WAIT_RELOAD); // delay ½ second
              }
```

```
else if(Rx_buffer[2] == 0x50) // Check if it is a left arrow key code
       abRGPData[2] = 0x50;
                                            //Start moving Slide backward
       while(!USBFS_bGetEPAckState(1)); //Wait for ACK before loading data
       //Load the endpoint and toggle the data bit
       USBFS_LoadInEP(1, abRGPData, 8, USB_TOGGLE);
       abRGPData[2] = 0x00;
                                                 //Reset buffer
       while(!USBFS_bGetEPAckState(1)); //Wait for ACK before loading data
       USBFS_LoadInEP(1, abRGPData, 8, USB_TOGGLE);
       SleepTimer_SyncWait(36, SleepTimer_WAIT_RELOAD); // delay by 1/2 second
}
else // If empty command
{
       abRGPData[2] = 0;
                                          // Do nothing to slides
       while(!USBFS_bGetEPAckState(1)); //Wait for ACK before loading data
       //Load the endpoint and toggle the data bit
       USBFS_LoadInEP(1, abRGPData, 8, USB_TOGGLE);
 }
} //end of while
} //end of main
void Initializations()
       M8C_EnableGInt;
                                          //Enable Global Interrupts
       SleepTimer_Start();
       SleepTimer_SetInterval(SleepTimer_64_HZ); // Set interrupt to a 64 Hz rate
       SleepTimer_EnableInt();
       //LCD_Start();
                                   // Initialize LCD
       // Initialize SPIM and the RF module itself
       SPIM_CS_Start(); // SPI master chip select
       SPIM_CS_On(); // Set chip select
       SPIM_Start(SPIM_SPIM_MODE_0 | SPIM_SPIM_MSB_FIRST);
       rf init();
                    // Initialize RF module
       rf_setChannel(RF_channel); // Select RF channel
} // end of Initializations
```